

**Product warranty**



Products have been strictly tested before leaving factory. If any malfunction occurs, please contact us or our agents immediately and provide details of the malfunction.

**Warranty**

The warranty is for one full year after the date that product is delivered at the designated place.

**Scope of warranty**

If any malfunction is caused by within the one-year warranty, we would repair the product free of charge.

The following situations are not covered by the warranty.

- If product is not used properly in accordance to the manual or technical requirements (including unsuitable conditions, unsuitable environment, etc.).
- If the malfunction is caused by purchasers or purchasers' software.
- If product is amended or fixed without permission.

**Setup Menu – Calibration**

Press **(1)**, Select 2.Calibration, and then **(2)** display:

Calibration  
0.Scale factor  
1.Set zero  
2.Low flow cut

0. Scale factor

Scale factor  
1.000

Refers to the ratio between "actual value" and "reading value". For example, when the measurement is 2.00, and it is indicated at 1.98 on the instrument, the scale factor reading is 2/1.98. This means that the best scale factor constant is 1.01.

1. Set zero: Press **(2)**; reset "Zero Point" which was set by the user.

Set zero Ent To set zero Reset zero	Set zero Waiting... SQ 88 Vel 0.035 m/s
---	--

2. Lowflow cut: Flow rate falls below the low flow cutoff value.

Low flow cut  
0.030 m/s

The flow indication is driven to zero. This function can prevent the flow meter from reading flow after a pump as shut down but there is still liquid movement in the pipe, which will result in totalization error. Generally, 0.03m/s is recommended to enter as the low flow cutoff point. The low flow cutoff value has no relation to the measurement results once the velocity increases over the low flow cutoff value.

3.Manual zero

Manual Zero  
0.000 m<sup>3</sup>/h

The seldom used calibration method is suitable for experienced operators to artificially input an offset superimposed on the measured value in order to obtain the true value when other calibration methods cannot be used well. For example:  
Actual measured value =250 m<sup>3</sup>/h  
The offset valve =10 m<sup>3</sup>/h  
Meter display =240 m<sup>3</sup>/h  
In general, this value should be set: "0".

**Setup Menu – Output**

Press **(1)**, Select 3.Output setting, and then **(2)** display:

Output setting  
0.RS485 Setup  
1.Alarm value

0. RS485 setup

RS485 Setup  
0.Network addr  
1.RS485 Baudrate

The window used to set serial port. It connection with the equipment of its serial port set of parameters must match. Move **(1)** or **(2)** can option baud rate: 2400, 4800, 9600, 19200. Data length fixed: 8 ;Stop bit for: 1. Factory serial port parameters for the default "9600, 8, None, 1".

1. Alarm value(Option)

Alarm value  
0.Low value  
1.High value

Enter the low alarm value; any of the measured flow, which is lower than the low value, will activate the alarm in the OCT hardware or relay output signal. Enter the high alarm value; any of the measured flow, which is higher than the high value, will activate the alarm in the OCT hardware or relay output signal.

**Setup Menu – Energy setting**

Press **(1)**, Select 4.Energy Setting, and then **(2)** display:

Energy setting  
0.Energy unit  
1.Temp. unit  
2.Flow position

The following options are available (by **(1)** or **(2)** buttons)  
0.Energy unit: Move **(1)** or **(2)** can option: GJ, MBtu, KWh, MWh.

1. Temp unit: Move **(1)** or **(2)** can option: C or F
2. Flow position: Move **(1)** or **(2)** can option: Inlet, Outlet
3. DT sensitivity: Move **(1)** or **(2)**. You can change the value
4. RTD Calib: Temperature sensor calibration

RTD Calibration 0.T1 K factor 1.T2 K factor	T1 K factor 0.998	T2 K factor 0.998
---	----------------------	----------------------

**Setup Menu – History Data**

Press **(1)**, Select 5.History Data, and then **(2)** display:

Date history  
0.By Day  
1.By Month  
2.By Year

0. By Day

Display: Daily heat totalizer (EHD), Daily cold totalizer(ECD), Daily Flow totalizer (ETD)

Day	00-20-08-18
EHD	3.188
ECD	6.889 KWh
FTD	6.866 m <sup>3</sup>

1. By Month

Display: Monthly heat totalizer(EHM), Monthk cold totalizer(ECM), Monthly Flow totalizer (ETM)

Month	00-20-08-18
EHM	9.188
ECM	9.889 KWh
FTM	9.866 m <sup>3</sup>


2. By Year

Display: Year heat totalizer(EHY), Year cold totalizer(ECM), Year Flow totalizer (ETM)


Year	00-20-08-18
EHY	88.196
ECY	96.889 KWh
FTY	89.866 m <sup>3</sup>

**Dimensions**

Model	DN	OD size	A (mm) Max	B (mm)	C (mm)
- 9.53	DN6	9.5-12	60	58	106
- 12.7	DN8	12-14	60	58	106
- 15	DN10	14-17	60	58	106
- 20	DN15	17-20	66	58	106
- 25	DN20	22-28	66	58	106
- 32	DN25	30-35	71	58	106
- 40	DN32	38-45	81	68	106
- 50	DN50	48-54	90	78	106
- 63	DN50	58-68	106	91	130
- 75	DN65	68-78	119	105	136
- 90	DN80	88-96	134	119	150
- 110	DN100	108-116	157	143	174



**Energy Meter  
Instruction Manual**



Version: A  
Date: Dec. 2020

**Notice**

Thank you for choosing Energy Meter.


This instruction manual contains the important using and operation information of the flow meter. Please read carefully the reference manual before operation to make your flow meter exert the best performance.

If you make a mistake there will be affected the meter's working and reduce the meter's life or cause some malfunctions.

**Product component**

Inspection should be made before installing the Flow meter. Check to see if the spare parts are in accordance with the packing list. Make sure that there is no potential damage to the enclosure due to a loose screw or loose wire, which occurred during transportation.




Any questions, please contact your representative as soon as possible.



**host Installation and connect**


host need to install flow sensor and temperature sensor, clean the pipeline before installation.

Make sure no dirt, paint, or other stains on the surface of the tube. Then put the bottom parts on the side of the pipe.



When the host is installed, the Energy meter is wired. Connect the DC power and RS485 output.

**Panel function**



**Powering on**

As soon as the host Energy meter is switched on, the self-diagnosis program will start to run.

SQ 88	12:30:29
Eq	135.28 GJ/H
EH	335.66 GJ
EC	35487.53 GJ


**Signal Quality (SQ value)**

SQ value is short for Signal Quality. It indicates the level of the signal detected. SQ value is indicated by numbers from 0-99 represents the minimum signal detected while 99 represent the maximum.

Normally, the transducer position should be adjusted repeatedly and coupling compound should be checked frequently until the signal quality detected is as strong as possible.

**Keypad Functions**

Follow these guidelines when using the Flow meter keypad:



- Setting or display mode, when it is setting mode, that can return to the previous menu, **(1)** and **(2)** scroll up and down to select the menu, when press **(1)** move to next digit, press **(1)** and the numbers scroll from 0 to 9, you can select the number. Press **(2)** to confirm.

**Window descriptions**

**Display Menu**

■ When the power on, the meter will display Velocity/Net Totalize.

SQ 88	12:30:29
Eq	135.28 GJ/H
EH	335.66 GJ
EC	35487.53 GJ

Display signal quality (SQ), time, heat power (Eq), heat totalizer (EH), cold totalizer (EC)

■ Press **(1)** will display T1, T2, delta T, press **(2)** will return to previous menu.

19-06-22	12:30:29
T1	11.38 C
T2	5.55 C
DT	5.832 K

Display date, time, outlet temp. (T1), inlet temp. (T2), Delta temp. (DT)

■ Press **(1)** will display Eq, EH, press **(2)** will return to previous menu.

SQ 88	12:30:29
Eq	12.933 GJ/H
EH	354.53 GJ

Display signal quality (SQ), time, Heat power (GJ/h), Heat totalizer (EH)

■ Press **(1)** will display Eq, EC, press **(2)** will return to previous menu.

SQ 88	12:30:29
Eq	95.651 GJ/H
EC	354.53 GJ

Display signal quality (SQ), time, heat power (Eq), cold totalizer (EC)

■ Press **(1)** will display Flow rate, Net totalizer, press **(2)** will return to previous menu.

SQ 88	12:30:29
Eq	11.651 m <sup>3</sup> /h
Net	354.53 m <sup>3</sup>

Display signal quality (SQ), time, flow rate, Net totalizer

■ Press **(1)** will display the Unit runtime, press **(2)** will return to previous menu.

Runtime	23 h
EHM	5.543 Kwh
ECM	7.248 Kwh
ETM	9.539 m <sup>3</sup>

Display Unit runtime, monthly heat totalizer (EHM), monthly energy totalizer (ECM), monthly flow totalizer (ETM)

**Setup Menu**

Press **(2)** will display Setup menu.

Setup menu	0.Pipe parameter
	1.System setting
	2.Calibration

The following options are available (by **(1)** or **(2)** buttons)

0. Pipe parameter
1. System setting
2. Calibration
3. Output setting
4. Energy setting
5. History Data

**Setup Menu – Pipe parameter**

Press **(1)**, Select 0.Pipe parameter, then **(2)** display:

Pipe parameter	0.Outer diameter
	1.Wall thickness
	2.Material

The following options are available (by **(1)** or **(2)** buttons)

0. Outer diameter
1. Wall thickness
2. Material: Move **(1)** or **(2)** can option PVC, Carbon steel, Steel, Copper pipe.
3. Fluid type: Move **(1)** or **(2)** can option Water, Sea Water, Oil...etc.

**Setup Menu – System setting**

Press **(1)**, Select 1.System setting, then **(2)** display:

System setting	0.System Unit
	1.Flow rate unit
	2.Total unit

The following options are available (by **(1)** or **(2)** buttons)

0. System unit : Move **(1)** or **(2)** can option Metric, English.
1. Flow rate unit : Move **(1)** or **(2)** can option m<sup>3</sup>/h, LPM, GPM.
2. Total unit : Move **(1)** or **(2)** can m<sup>3</sup>, L, GAL.
3. Totalize RESET : All parameters are reset, Press **(2)**, move **(1)** or **(2)** arrow to select "YES" or "NO". After "YES" is selected.

**4. Time set**

yy-mm-dd hh:mm
19-06-20 12:30

Generally, it is unnecessary to modify date time as the system is provided with a highly reliable perpetual calendar chip.

**5. System lock**

System lock System unlocked	System lock ENT to lock	ENT key word 0000	System lock System locked OK
System lock System locked	System lock ENT to unlock	ENT key word 0000	System lock System unlocked OK

Once the system is locked, any modifications to the system are prohibited, but the parameter is readable. "Unlock" using your designated password. The password is composed of 1 to 4 numbers.

**6. System INFO**

System INFO Energy meter SN:E0001356 V1.02	Manual Totalizer ENT To Start	Manual Totalizer ENT To Stop 1.239 m <sup>3</sup> /h SQ 88 1.056L	Manual Totalizer ENT To Restart 1.239 m <sup>3</sup> /h SQ 88 1.056L
---	----------------------------------	--	---

System INFO: Display serial number (SN) of the meter. This SN is the only one assigned to each flow meter ready to leave the factory. The factory uses it for files setup and for management by the user. Set zero: Press **(2)**; reset "Zero Point" which was set by the user. Manual Totalizer: The manual totalize is a separate totalize. Press **(2)** to start, and press **(2)** to stop it. It is used for flow measurement and calculation.

**7. Display dir**

Display dir	0.Normal
	1.Inversion

Can choose the direction of display, convenient to observe the measurement data.